


В

Fix back panels C and D together using cam fittings K and cam

Turn unit so that right hand back panel **D** is on the floor. Fix top rail **E** to back panel **D**. Fix end panel A to back C, bottom G and rail E. Use a rubber to gently tap down the panel. Tighten cams in a clockwise direction with a suitable screwdriver. (Do not use an electric screwdriver.) C G Ε D Turn unit upside down to fit legs to panel **G**. (See notes below.)



Fit metal 'L' brackets to back of unit using 2 x 14mm Euro screws. Cap access holes in back panel using 18mm cover caps. If a shelf is being fitted, position 4 shelf pegs L to shelf holes in back panels and rear holes in end panels. Drop shelf **H** into position, then fit 2 front retaining pegs M / N to front holes in ends, (as shown). Finally fit two top retaining pegs P to rear holes above shelf on end panels.(Note the shelf should be fitted before worktops are fitted above the unit.) If a carousel fitting is to be used, discard the shelf and fit the wire work.


CP 0001

## CG 0010 CL 0002 Fit the leg bosses into the base panel of the unit. Turn the leg boss so the flange Н bottom of the leg. If necessary a flathead screwdriver can be used in the slots CL 0009


CL 0003

Fix corner post to door using 45mm Carcase screws M. Lay the door on a flat surface, line up the post with the door edge and mark the hole positions on the door edge. (This can be done by pressing the carcase screw through the hole in the corner post and into the

Pilot drill the door edge in the positions marked using a 3mm drill bit,





Screw fix hinges to each door and fit door buffers to corners of door as shown.





Hinge adjustment

By turning the hinge adjuster screws as shown the doors can be adjusted in various directions.












Screw fix the corner post to the door using 4 x 45mm Carcase screws M. Position a plastic washer R on each screw between the post and the door to give the correct spacing.




Clip hinges onto hinge plates. To release hinges from plates, lift the rear release clip as shown.




When using drawer line doors, the door and drawer front must be strapped together using the CP 0004 Connecting plates and screws CG 0006 as shown. (A gap of 4mm should be maintained between the door and drawer front.)



Bore each door and fit handles.





CG 0006





extends over the end panels. If the leg boss is at the front of the unit, the flat edge of the flange must be square to the end panel or it will foul the plinth. Tap the centre pin of the leg boss down until it is flush with the panel. (This does not need great force.)

C

Fix leg boss using 2 x No 6 1/2" screws.

Use a rubber mallet to gently tap down

the panel. Tighten cams in

a clockwise

screwdriver


screwdriver.)


electric


direction with a suitable


(Do not use an

Take care turning the unit over. (We recommend 2 people) Do not allow the full weight of the unit to rest on the legs before the unit is upright. Push adjustable leg into leg boss. Adjust the height of the unit by turning the









G

Α

